



Reference No.	Part No.	Description	Reference No.	Part No.	Description	Reference No.	Part No.	Description	
1	MFT 160-419	Centershaft	15	MFT 160-435	Roller Bearing – Front	39	MFT 160-459	Hub Key (2)	
2	MFT 160-420	Centershaft Cone, 3-1/2" (88.9 mm)	16	MFT 160-436	Roller Bearing – Rear	40		Expansion Wedges (3)	
	MFT-160-478	Centershaft Cone, 4" (101.6 mm)	17	MFT 160-437	Needle Bearing – Rear		MFT 160-460	4-1/2" - 5-1/2" (114.3 - 139.7 mm)	
3	MFT 160-423	Screw – Wedge Guide (12)	18	MFT 160-438	Rear Housing		MFT 160-470	5-1/2" - 6-1/2" (139.7 - 165.1 mm)	
4	MFT 160-424	Wedge Guide, 3-1/2" (88.9 mm)	19	MFT 160-439	Screw – Rear Housing (12)		MFT 160-471	6-1/2" - 7-1/2" (165.1 - 190.5 mm)	
	MFT 160-479	Wedge Guide, 4" (101.6 mm)	20	MFT 160-440	Pipe Plug		MFT 160-472	7-1/2" - 8-1/2" (190.5 - 215.9 mm)	
	MFT 160-480	Wedge Guide, 7" (177.8 mm)	21	MFT 160-441	Seal – Rear Housing		MFT 160-473	8-1/2" - 9-1/2" (215.9 - 241.3 mm)	
5	MFT 160-425	Draw Rod	22	MFT 160-442	Centershaft Lock		MFT 160-474	9-1/2" - 10-1/2" (241.3 - 266.7 mm)	
6	MFT 160-426	Toolholder	23	MFT 160-443	Feed Nut Retainer Ring		MFT 160-475	10-1/2" - 11-1/2" (266.7 - 292.1 mm)	
7	MFT 160-427	Seal	24	MFT 160-444	Feed Nut		MFT 160-476	11-1/2" - 12-1/2" (292.1 - 317.5 mm)	
8	MFT 160-428	Screw – Toolholder (39)	25	MFT 160-445	Feed Handle (4)		MFT 160-477	12-1/2" - 13-1/2" (317.5 - 342.9 mm)	
9	MFT 160-429	Seal – Front Housing	26	MFT 160-481	Motor Sub Plate	41	MFT 160-461	Spring (3)	
10	MFT 160-430	Front Housing	27	MFT 160-447	Driveshaft Bearing (2)	42	MFT 160-462	Control Knob (4)	
11	MFT 160-431	Center Hub	28	MFT 160-483	Driveshaft	43	MFT 160-486	1/4"-20 x 1" Socket Head Cap Screw (8)	
12	MFT 160-432	Worm Gear	29	MFT 160-449	Worm Gear	44	MFT 160-485	3/8"-16 x 1" Socket Head Cap Screw (4)	
13	MFT 160-433	Screw – Worm Gear (6)	30	MFT 160-450	Access Cap		45	MFT 160-465	15/16" Combination Wrench
14	MFT 160-434	Needle Bearing – Front	31	MFT 160-451	Screw – Access Cap (4)		46	MFT 160-466	5/32" T-Handle Hex Key
			32	MFT 160-452	Seal – Driveshaft		47	MFT 160-467	Cap Screw (6)
			33	MFT 160-453	Thrust Bearing (2)		48	MFT 160-484	1/4" Square Key
			34	MFT 160-454	Screw – Retainer Ring (6)		49	MFT 160-487	Hydraulic Motor
			35	MFT 160-455	Inner Race		50	MFT 160-342	Feed Nut Cap Screw
			36	MFT 160-456	O-Ring		51	MFT 160-482	Motor Adapter
			37	MFT 160-457	Thrust Bearing				
			38	MFT 160-458	Driveshaft Key				